



# Decon/Pak™

## GROSS DECON SIMPLIFIED

The DECON/pak portable decontamination system is a self-contained agent proportioning and rinse application system developed specifically for gross decontamination of firefighting personnel and equipment.



Decon/Pak

## FEATURES



Use your favorite variety of approved PPE cleaning agent and proportion from 0.1% to 0.5% or choose to rinse with water only.



One firefighter, one hoseline. Gone are the days of unorganized on-scene decon procedures. Quickly decon so your crew can get back to the station.



Designed for gross decon, not a storage container or seat like many 5-gallon buckets end up.



Made of the highest quality materials with precision machining - the Decon/Pak endures life on fire apparatus and perform as expected



Compact for storage and access so your crews can easily store, carry, and deploy with ease.

## GROSS DECON SIMPLIFIED

- 1 DETERGENT TANK**  
The rugged green polypropylene 2.5 gallon concentrate tank is suitable for use with your PPE recommended detergent.
- 2 INTEGRATED TWIST SHUT-OFF VALVE**  
Designed for ease-of-use, once you've connected a supply line, attached the nozzle, and selected a mix percentage, simply twist to start flowing.

- 3 DETERGENT METERING KNOB**  
Agents used in the DECON/pak are to be diluted according to the manufacturer's specifications. The DECON/pak delivers agent at between 0.1 and 0.5%.

- 4 1" OR 1.5" PRESSURIZED SUPPLY LINE**  
Water is supplied by a pressurized 1" or 1.5" hose line that operates between 40-500 PSI (3-40 bar).

- 5 LARGE, EASY-OPEN FILL PORT**  
Unscrew the fill port lid by turning counterclockwise. Fill tank to bottom of fill port. Agent may seep out the vents if over filled. Close the fill port lid by turning clockwise.



## PRODUCT SPECIFICATIONS

WEIGHT	SIZE	FLOW	PROPORTIONING	TANK CAPACITY
14.5 lbs	13.5" x 10.75" x 17"	12 GPM @ 100 PSI	0.1% TO 0.5%	<b>2.5 gal</b>
6.5 kg	345mm x 275mm x 430mm	45 L/MIN @ 6.8 BAR		<b>9.5 liters</b>

## PRODUCT LIST

ITEM	COUPLING	LANGUAGE
UM12-NF-D	1.5" NHF	ENGLISH
UM12-D	1.0" NHF	ENGLISH
UM45-BD-D	1.0" BSPF METRIC	ENGLISH
UM45-BIC-D	2.5" BICM METRIC	ENGLISH

ITEM	COUPLING	LANGUAGE
UMP45-SH-D	52MM STORZ	PORTUGUESE
UMS45-BD-D	1.0" BSPF METRIC	SPANISH
UM45-SH-D	52MM STORZ METRIC	ENGLISH

Visit [tfthealth.com](http://tfthealth.com) to learn more about the **Decon/Pak** and its place on your apparatus.